

Manufacturer	Part #	Model #	Type
AJAX	5953	74	FLOOR
AJAX	5903	2700	BUMPER
AJAX	5904	2754	FLOOR
AJAX	5918	2782	FLOOR
AJAX	5953	2784	FLOOR
AJAX	5922	2903	BUMPER
AJAX	5933	2936	HAND
AJAX	5707	2963	HAND
AMERICAN	5501	JX-107,J-120H, SX-1,07,120H	H & B
AMERICAN	5504	JX-809.JX810.5,SX-809,810.5	HAND
AMERICAN	5505	JX-1209,J-1211,SX-1209,1211	HAND
AMERICAN	5507	FC1-1/2,SFG-1-1/2	FLOOR
AMERICAN	5639	FJ-150	FLOOR
AMERICAN	5648	FJ-200	FLOOR
AMERICAN	5635	FJ-400	FLOOR
ARO	5639	645-051	FLOOR
ARO	5648	645-052,052R	FLOOR
ARO	5635	645-053R,053	FLOOR
AUSCO	5530	A-10-12	TRUCK CRANE
AUSCO	5535	A 10-25	SHOP CRANE
AUSCO	5530	D-1501,1503-A,1503-B,1503C	HAND
AUSCO	5534	D-1521.1523A,1518A	HAND
AUSCO	5535	D-1523B.1528B,1523C,1528C	HAND
AUSCO	5539	ALL 8 TON SERIES	HAND
AUSCO	5541	D-1543B,1548B,1543C,1548C	HAND
AUSCO	5542	ALL 12 TON SERIES	HAND
AUSCO	5543	D-1553	HAND
AUSCO	5549	D-7200	FLOOR
AUSCO	5550	D-7400,10-259	FLOOR
AUSCO	5552	D-8000,10-8,10-8-1,10-8-3	END LIFT
AUSCO	5550	D-8200	TRANSMISSION
AUSCO	5706	10-2	HAND
AUSCO	5707	10-3	HAND
AUSCO	5570	13-51	PUMP
AUSCO	5573	13-52	PUMP
AUSCO	5572	13-100	RAM
AUSCO	5571	13-101	RAM
AUSCO	5575	13-102	SPREADER
AUSCO	5575	13-110	RAM
BEAR	5604	W-123,W-124	HAND
BLACKHAWK	5594	BA8.5-2,BA8.10-2,BA8.5D	HAND
BLACKHAWK	5600	ALL CB9 SERIES	HAND

Size
4
1-1/2
1-1/2
2
4
1-1/2
5
100
1-1/2
8
12
1-1/2
1-1/2
2
4
1-1/2
2
4
1/2
2
1-1/2
5
5
8
12
12
20
1-1/4
1-1/2
1-1/2
1
50
100
4
10
4
4
1
10
12
3
8

Manufacturer	Part #	Model #	Type
BLACKHAWK	5601	DB.7-3,DB.7E	HAND
BLACKHAWK	5603	ALL DB.7 SERIES	HAND
BLACKHAWK	5604	D11-3	HAND
BLACKHAWK	5606	EA11-C	HAND
BLACKHAWK	5608	ALL EA SERIES	HAND
BLACKHAWK	5612	GB-11C	HAND
BLACKHAWK	5706	GC-12	HAND
BLACKHAWK	51004	J-12,J-12B,J-14	BUMPER
BLACKHAWK	5707	NC-12	HAND
BLACKHAWK	51010	S-3	FLOOR
BLACKHAWK	5635	S-4-1,S-4-H,S-4-J	FLOOR
BLACKHAWK	5636	S-7	FLOOR
BLACKHAWK	5639	S-17,S-17D.S-23,S-23C	FLOOR
BLACKHAWK	5648	SJ-18	FLOOR
BLACKHAWK	5619	P-200C	PUMP
BLACKHAWK	5623	R-28,R75	RAM
BLACKHAWK	5626	R-112,R113	RAM
BLACKHAWK	5627	R-158,R-225B,R-251,R-251A	RAM
BLACKHAWK	5628	R-159,R75-2,R78	RAM
BLACKHAWK	5630	R-210-B	RAM
BLACKHAWK	5633	R-325,R-618	RAM
BLACKHAWK	5643	S-80(P-85-B & R-210B)	PUMP & RAM
BLACKHAWK	5644	SA-5(P-200-C & R-325)	PUMP & RAM
BUDA	5501	1.5-7,1.5-21	HAND
BUDA	5504	8-9,8-11	HAND
BUDA	5712	8-9A	HAND
BUDA	5505	12-9,12-11	HAND
BUDA	5714	12-9A	HAND
DREDNAUT	5530	D-1601A,D-1601B	HAND
DREDNAUT	5531	D-1611,D-1616	HAND
DREDNAUT	5534	D-1621,D-1626	HAND
DREDNAUT	5535	D-1621B,D-1626B	HAND
DREDNAUT	5539	ALL 8 TON SERIES	
DREDNAUT	5541	D-1641B,D1646B	HAND
DREDNAUT	5542	ALL 12 TON SERIES	
DREDNAUT	5543	D-1651	HAND
DREDNAUT	5706	10-2	HAND
DREDNAUT	5707	10-3	HAND
DREDNAUT	5577	10-121	HAND
DREDNAUT	5578	10-122	HAND
DREDNAUT	5579	10-123	HAND
DREDNAUT	5579	10-124	HAND

Size
12
12
12
20
20
50
50
1-1/2
100
1-1/2
4
1-1/2
1-1/2
2
2
7
12
20
10
50
2
50
2
1-1/2
8
8
12
12
1-1/2
3
5
5
8
12
12
20
50
100
1-1/2
3
5
8

Manufacturer	Part #	Model #	Type
DREDNAUT	5580	10-125	HAND
DREDNAUT	5583	10-126	HAND
DUFF-NORTON	5933	5H-9	HAND
DUFF-NORTON	5951	30H-11(Old Style),Dual Pumps	HAND
DUFF-NORTON	5706	50H-12	HAND
DUFF-NORTON	5707	100H-12	HAND
ENERPAC	5706	JH-50	HAND
ENERPAC	5707	JH-100	HAND
FLEET	5530	5-1,5-01	HAND
FLEET	5535	5-3,5-17	HAND
FLEET	5541	5-5,5-19	HAND
FLEET	5543	5-6	HAND
FLEET	5706	5-8	HAND
FLEET	5707	5-9	HAND
FLEET	5549	5-25	FLOOR
FLEET	5550	5-26,5-35,5-48	FLOOR & TRANS
FLEET	5552	5-31,5-41,5-42,5-21	END LIFT
FLEET	5530	5-87	SHOP CRANE
FLEET	5535	5-91	SHOP CRANE
FLEETMASTER	5570	5-151	PUMP
FLEETMASTER	5573	5-152	PUMP
FLEETMASTER	5572	5-160	RAM
FLEETMASTER	5571	5-161	RAM
FLEETMASTER	5575	5-162	SPREADER
FLEETMASTER	5575	5-170	RAM
GMC	5933	2233038	HAND
GMC	5945	2233041	HAND
GREENLEE	5691	775	BENDER
HANDY-ANDY	5712	E8.9B	HAND
HANDY-ANDY	5714	E12.9B	HAND
HEIN-WERNER	5706	50.12AA	HAND
HEIN-WERNER	5702	55	END LIFT
HEIN-WERNER	5707	100.12AA	HAND
HEIN-WERNER	5712	E8.9A,E8.11A	HAND
HEIN-WERNER	5714	E12.9A,E12.11A	HAND
HEIN-WERNER	51025	GH	FLOOR
JOYCE	5702	7-M	BUMPER
JOYCE	5756	2-Ster	FLOOR
JOYCE	5758	H-39	HAND
JOYCE	5760	H-89	HAND
JOYCE	5612	J-5011	HAND
JOYCE	5707	J-10012(Hhein-Werner)	HAND

Size
12
20
5
30
50
100
50
100
1-1/2
5
12
20
50
100
1-1/4
1-1/2
1-1/2
3/4
2
4
10
4
4
1
10
5
20
8
12
50
1-1/2
100
8
12
4
1-1/2
2
3
8
50
100

Manufacturer	Part #	Model #	Type
KENT-MOORE	5626	J-6180	RAM
MANLEY	5774	J-2	FLOOR
OTC-OWATONNA	5633	YS-2A	RAM
OTC-OWATONNA	5628	YS-10A	RAM
OTC-OWATONNA	5627	YS-20A	RAM
OTC-OWATONNA	5630	YS-50A	RAM
PORTER-FERGUSON	5816	BU404A	RAM
SEARS-ROEBUCK	5933	1242	HAND
SEARS-ROEBUCK	5945	1273	HAND
SIMPLEX	5851	5HJ	HAND
SIMPLEX	5702	BJ-530	END LIFT
SNAP-ON	5639	JFJ-150	FLOOR
SNAP-ON	5635	JFJ-400	FLOOR
WALKER	5903	707,707A	BUMPER
WALKER	5904	754,764	FLOOR
WALKER	5911	782-ABC	FLOOR
WALKER	5912	782E,882A	FLOOR
WALKER	5913	783-BCD	FLOOR
WALKER	5918	FITS ALL 782,882 SERIES	FLOOR
WALKER	5919	882B	FLOOR
WALKER	5953	FITS ALL 784,884 SERIES	FLOOR
WALKER	5921	901,905,906	H & B
WALKER	5922	903	BUMPER
WALKER	5930	930D,930L,931	HAND
WALKER	5933	FITS ALL 930 Except R	HAND
WALKER	5938	945D,945L,946	HAND
WALKER	5942	950,950E	HAND
WALKER	5945	FITS ALL 952 SERIES	HAND
WALKER	5947	953E(Single Pump) J-953	HAND
WALKER	5951	FITS ALL 960 Except I	HAND
WALKER	5706	965-I,J-965	HAND
WALKER	5707	970A,J970	HAND
WALKER	5530	J-814-A	SHOP CRANE
WALKER	5535	J-817-A	SHOP CRANE
WALKER	5530	J-818A	TRUCK CRANE
WEAVER	5530	WA-15	HAND
WEAVER	5535	WA-50	HAND
WEAVER	5549	WA-66	FLOOR
WEAVER	5550	WA-67	FLOOR
WEAVER	5970	FITS ALL WA 72 SERIES	FLOOR
WEAVER	5541	WA-120	HAND
WEAVER	5543	WA-200	HAND

Size
12
2
2
10
20
50
7-1/2
5
20
5
1-1/2
1-1/2
4
1-1/2
1-1/2
2
2
3
2
2
4
1-1/2
1-1/2
5
5
12
20
20
20
30
50
100
1/2
2
1/2
1-1/2
5
1-1/4
1-1/2
2-1/2
12
20

Manufacturer	Part #	Model #	Type
WEAVER	5706	WA-500	HAND
WEAVER	5707	WA-1000	HAND
WESTERN	5714	12-9A	HAND
WESTERN	5706	50-B-12A (Steel Base)	HAND
WESTERN	5707	100-B-12	HAND
WESTERN	5501	1.5-7,1.5-21	HAND
WESTERN	5504	8-9,8-11	HAND
WESTERN	5712	8-9A	HAND
WESTERN	5505	12-9,12-11	HAND
WESTERN	5714	12-9A	HAND
WHITE MOTOR CO.	5933	397231	HAND

Size
50
100
12
50
100
1-1/2
8
8
12
12
5