

Pat #	Description	Quantity in Stock
A1157		002
A1494	LEVER ROLLER BKN	009
A1536		
A1536C	CLUTCH PLATE ASSY FOR BKN	001
A1696A		
28-A3617		001
AB78	USED	001
AB78J	USED	003
AB93	CYLINDER HEAD (USED)	001
AB99D	CYLINDER HEAD (USED)	004
AB99P	CYLINDER HEAD (USED)	004
AB99Q	CYLINDER HEAD (USED)	001
AB99Q	CYLINDER HEAD (NEW)	001
AB99T	CYLINDER HEAD (USED)	001
AB100A	SEE AB86A	
AB101B	SEE AB93	
AB101	CYLINDER HEAD (USED)	001
AB101B	CYLINDER HEAD (NEW)	001
AD42	VALVE GUIDE	006
AD43	VALVE GUIDE	001
AE73D	VALVE EXHAUST	002
AE73N	VALVE EXHAUST	001
AE74C	VALVE EXHAUST	001
AE75B	VALVE INLET & EXHAUST	007
AE75D	VALVE EXHAUST	003
AE75DS4	VALVE EXHAUST	001
AE76D	VALVE EXHAUST	001
AE76E	VALVE INLET & EXHAUST	003
AE76ES4	VALVE INLET & EXHAUST	001
AE76N	VALVE INLET	001
AF43	VALVE SPRING	002
AF43B	VALVE SPRING	005
AF50	VALVE SPRING	004
AF51	VALVE SPRING	007
AF52	SEE AF50	
AF54	VALVE SPRING	004
AF56	VALVE SPRING	001
AG26	SEAT VALVE SPRING (USED)	010
AG34A	CUP LOCATING SPRING	001
AH9	RETAINER LOCK	012
BB116B	BASE CAST IRON (USED)	007
BB116B	BASE ALUMINUM (USED)	009

Pat #	Description	Quantity in Stock
BB128A	BASE ENGINE (USED)	001
BD100C	GEAR COVER	002
BD103BS1	GEAR COVER	001
BD103GS1	SEE BD103BS1	
BG170	BEARING PLATE	002
BG170-8S2	SEE BG170	
BG194A	BEARING PLATE	001
BG210	PLATE BEARING	001
BG241	PLATE BEARING	005
BH103	INSPECTION PLATE FOR VG4D	001
BH110	USED ON VG4	001
BH155A	CRANKCASE COVER	001
BI243AS1		001
BI266S1	BRACKET AIR CLEANER ASSY	001
BI266S1	BRACKET AIR CLEANER ASSY (USED)	001
BI291	BRACKET AIR CLEANER	001
BK97		001
CA48D	CRANKSHAFT W/BRGS	001
CA51-2	CRANKSHAFT	001
CA55-17D	CRANKSHAFT	001
CA55S1	CRANKSHAFT	002
CA69-50	CRANKSHAFT	001
DA48AS30	CONNECTING ROD	001
DA48AS10	CONNECTING ROD	001
DA49BS1	CONNECTING ROD (USE HA139S BRG.)	001
DA49AS30	CONNECTING ROD	001
DA51BS1	CONNECTING ROD	002
DA51BS30	CONNECTING ROD	002
DA62S1	CONNECTING ROD	002
DA62S10	CONNECTING ROD	001
DA62S30	CONNECTING ROD	002
DA66AS1	CONNECTING ROD	004
DA68S1	CONNECTING ROD	003
DA70BS1S	CONNECTING ROD (S30)	002
DB160B	PISTON (STD)	001
DB183D1	PISTON (.010)	003
DB186A	PISTON (SEMI-FINISHED)	001
DB187-3	PISTON (USE DB209)	
DB190AS10	PISTON (.010 CG)	002
DB208S30	PISTON (.030)	004
DB209-5	PISTON	001
DE59	PISTON PIN	001

Pat #	Description	Quantity in Stock
DE59S5	PISTON PIN +.005	001
DE62	PISTON PIN	006
DE62S10	PISTON PIN +.010	002
DE65	PISTON PIN	003
DE65S5	PISTON PIN +.005	001
DE65S10	PISTON PIN +.010	003
DE65S20	PISTON PIN +.020	001
DE66	PISTON PIN	001
DE66S5	PISTON PIN +.005	001
DE67	PISTON PIN	002
DE67S5	PISTON PIN +.005	001
DE67S10	PISTON PIN +.010	001
DE68	PISTON PIN	002
DE68S5	PISTON PIN +.005	003
DR1	RING SET	001
DR2S30	RING SET +.030	001
DR3S30	RING SET +.030	001
DR6S60	RING SET +.060	001
DR7	RING SET	001
DR7S20	RING SET +.020	001
DR7S30	RING SET +.030	001
DR8	RING SET	002
DR8S10	RING SET +.010	002
DR8S30	RING SET +.030	001
DR9	RING SET	001
DR10	RING SET	002
DR10S10	RING SET +.010	001
DR10S20	RING SET +.020	001
DR12S30	RING SET +.030	001
DR19S20	RING SET +.020	001
DR30	RING SET	001
DR32S10	RING SET +.010	001
DR41S30	RING SET +.030	001
EY25W	MUFFLER FOR ROBIN	001
E436-A-5	KEYS	002
EA101ZS1	CAMSHAFT & GEAR ASSY	001
EA102	CAMSHAFT	001
EA102	CAMSHAFT W/GB45A GEAR (USED)	001
F63	TAPPET VALVE W/LOCKSCREW	005
FA42A	VALVE TAPPET	001
FA42C	VALVE TAPPET	001
GA35A1	GEAR CRANKSHAFT	001

Pat #	Description	Quantity in Stock
28GB8	BRUSH SET	001
GD93C1	GEAR MAGNETO	001
GD98	GEAR GOVERNOR	001
GD97C	GEAR GENERATOR	001
GD103	GEAR MAGNETO	002
GE50	GEAR	002
GE61	GEAR MAG & PUMP	001
GF85	GEAR	002
GH35A1		001
GJ10	CHAIN - REDUCTION GEAR	001
GT121B		002
HA133S	SHELL BRG - STD	002
HA138S	SHELL BRG STD	001
HG133A1	BUSHING - PISTON PIN	001
HF236	WASHER	011
HF238	WASHER	009
HF430		001
HG131A1	BUSHING - PISTON PIN	001
HG150A	INSERT - VALVE SEAT	004
HG150D	INSERT - VALVE SEAT	004
HG157A1	BUSHING - PISTON PIN	004
HG182	BUSHING	002
HG201	INSERT - VALVE SEAT	006
HG201D	INSERT - VALVE SEAT	005
28IAT3076ES	USE YQ24	
28IG579A	BEARING	002
28IG1324J	DISTRIBUTOR CAP	002
28IGB264		008
28IGB1001B	DISTRIBUTOR CAP	001
28IGB1007S	CLAMP	001
28IGB1239	ROTOR	001
28IGC1107S		001
28IGS1016B		001
28IGS2224LB	BREAKER CONTACT	
28IGW3028YS	USE YQ24	
28IGW3143L		001
28IGW4179		001
JK59	O'RING	001
K57		001
93K501	ZENITH REPAIR KIT	001
93K739	ZENITH REPAIR KIT	001
K99BS2	OIL PUMP ASSY.	001

Pat #	Description	Quantity in Stock
93K2063	ZENTIH REPAIR KIT	001
90K9358	WICO KIT	001
ka56	BODY- OIL PUMP	001
KA61AS1	BODY - OIL PUMP (KA61DS1)	001
KA64-3S1	BODY - OIL PUMP ASSY (KA64AS1)	001
KB42S2	COVER - OIL PUMP	002
KF14S1	PLUNGER - OIL PUMP ASSY	002
L51E-S1	CARBURETOR	001
L52CS1	CARBURETOR	001
L51LS1	CARBURETOR	001
LC270A	MANIFOLD	001
LD222	MANIFOLD	001
LD228	MSNIFOLD (GOOD USED)	001
LD232	MANIFOLD	001
LD245	MANIFOLD	001
LJ315	NIPPLE - PIPE	008
LL92	HOSE (USE LL125)	001
LO64	AIR CLEANER ASSY	001
LO74	PRE-CLEANER (USE LO114)	
LO114	PRE-CLEANER	001
LO97	CLEANER AIR ASSY (USE LO158S2)	
LO113A	CLEANER -AIR OIL BATH	001
LO158S2	CLEANER AIR ASSY	001
LO173B	ELEMENT	006
LO31B	BREATHER	008
63LM408	ROLLERS	004
LP19	FUEL BOWL	001
LP62AS1	FUEL PUMP	002
LQ31	FUEL BOWL KIT	001
LQ32	FUEL BOWL KIT	001
M496	SEE (M1930A)	
M1930A		002
28MBG3005AS	FIELD COIL	001
ME38A	STEEL BALL	003
ME115	NEDDLE BEARING	003
MH187	V-BELT	001
28MZ2012AS	COMP BRUSH (1733)	001
NC140G	FL YWHEEL	001
NC143	FLYWHEEL	001
NC146	FLYWHEEL	001
OA130B	DISC COUPLING 0 MAGNETO	001
PA291	PIN DOWEL	001

Pat #	Description	Quantity in Stock
PA333	ROLL PINS	003
PA340	ROLL PINS	004
PB147	SCREW ADJUSTING	016
PB148S1	BOLT CONNECTING ROD ASSY	002
PB160	STUD	001
PB169A	SCREW	001
PC110	STUD 3/8 X 2-1/8	004
PC112	STUD 5/16 X1-7/8	005
PC321	STUD 3/8 X 3-1/16	001
PC337	STUD S/SPCPC615 (7/16 X 11)	007
PC368	STUD 1/4 X 15/16	002
PC369	STUD 3/8 X 1-7/8	018
PC372	SEE PC372A	
PC372A	STUD 1/4 X 3-9/16	004
PC435	STUD 1/2 X 1-13/16	004
PD9	NUT 1/4 X 28	004
PD13	NUT 1/2 X 20	011
PD77	NUT 1/4 X 20	001
PD115	NUT 10 X 32	001
PD123	NUT 1-1/8 X 12	001
PD141	NUT 5-16 X 24	002
PD173A	NUT 10-32	001
PD181	NUT 5/16 X 24 (USE PD246)	037
PD206	NUT 3/8 X 24	004
PD246	SEE (PD181)	
PD251	GRIPCO NUT 1/4 X 28	001
PE4	LOCKWASHER 5/16	004
PE7	LOCKWASHER 1/2	013
PE37A	STAR WASHER 5/8	009
PE57	STAR WASHER 5/8	002
PE59	STAR WASHER 1-5/32	005
PE65-1	STAR WASHER 1-9/32	005
PE66	STAR WASHER (SEE PE59)	
PE73	STAR WASHER 7/8	001
PE82	LOCKWASHER 21/64	000
PF18	PLUG PIPE 1/8	005
PF118	RETAINERS OIL	007
PG321	STRAP FUEL TANK	004
PG343	CLIP SUPORT	001
PG466		001
PG488	STRAP FUEL TANK	003
PG751	BRACKET ADJUSTING STRAP	001

Pat #	Description	Quantity in Stock
PH22	WASHER PLAIN 25/64	005
PH30	WASHER PLAIN 17/64	017
PH77	WASHER PLAIN 11/32	005
PH202	SEAL	001
PH234A	SEAL	001
PH245	CORK WASHER	001
PH253	WASHER PLAIN 11/64	001
PH254	RETAINER	005
PH256	SEAL	009
PH272A	USE PH272B	
PH272B	SEAL	002
PH279	RETAINER HUB	002
PH280	SEAL	001
PH282	CUP WASHER 17/64	001
PH310		003
PH313	WASHER	008
PH318A	SEAL	003
PH364	SEAL OIL	001
PH426	GROMMET 1-13/16	001
PH557A	SEAL 1-1/2	001
PH612		006
PI115F	SCREW ADJUSTING 10-32X5 11/16	001
PI147B	SCREW ADJ. 10-32X10-1/2	001
PJ105	STUD IDLER GEAR	001
PK37	RING RETAINING (PK37A)	005
PK50A	RETAINER BALL	002
PK52	RING RETAINING	008
PK56		001
PL17	WOODRUFF KEY 13	006
PL49	WOODRUFF KEY 15	002
PL83	WOODRUFF KEY 23	003
PL87	WOODRUFF KEY 22	005
PL217		001
PM76	SPRING	001
PM140	SPRING	001
PM141	SPRING	001
PM142	SPRING	003
PM165	SPRING	001
63PT534		001
63PT583	SEAL	001
63PT584	PLUG	001
Q2B	GASKET SET	001

Pat #	Description	Quantity in Stock
Q22	GASKET SET (AEND,AENLD)	001
Q24	GASKET SET (ACN)	001
Q31	GASLET SET (AGND)	001
Q34A	GASKET SET (V461D)	001
Q38	GASKET SET (S10D, S12D)	001
Q38A	GASKET SET	001
Q42	GASKET SET (TRA12D)	001
QA112	SHIM	009
QA113	SHIM	008
QA114	SHIM	007
QB47	GASKET	006
QB77	GASKET- INTAKE MANIFOLD	016
QB78	GASKET- EXHAUST MANIFOLD	026
QB85	INSERT-EXHAUST MANIFOLD	005
QC12A	GASKET-CARBURETOR	002
QC52		005
QC55A	GASKET-MANIFOLD	002
QC70	GASKET-MANIFOLD	001
QD423B		001
QD476-7	HEAD GASKET	002
QD477		001
QD479A	GASKET-BEARING PLATE	020
QD479C	GASKET-BEARING PLATE	003
QD481	GASKET-INSPECTION PLATE	001
QD482	GASKET-VALVE TAPPET PLATE	008
QD486	GASKET-VALVE TAPPET PLATE	045
QD487A	GASKET-BEARING PLATE	005
QD489B	GASKET-OIL PAN	002
QD514B	GASKET-ENGINE BASE	001
QD516	GASKET-MAGNETOR	002
QD518	GASKET-BEARING RETAINER PLATE	002
QD525	HEAD GASKET	001
QD538A	GASKET-FUEL PUMP	007
QD540	GASKET-AIR CLEANER	001
QD546	SEAL-OIL REDUCTION GEAR	002
QD571	GASKET-GOV. SHAFT BRACKET	011
QD573	GASKET-BEARING PLATE	008
QD573A	GASKET-BEARING PLATE	005
QD574	GASKET-BEARING RETAINER PLATE	002
QD596	GASKET-GEAR COVER	001
QD613C	HEAD GASKET (SOME RUST)	001
QD616	GASKET-MAGNETOR	001

Pat #	Description	Quantity in Stock
QD631	HEAD GASKET (VG4D) SOME RUST	002
QD632	GASKET-CYLINDER BASE	004
QD635A	GASKET-OIL PAN	001
QD636	GASKET-BEARINNG PLATE	003
QD647	GASKET-AIR CLEANER BRACKET	004
QD661A	GASKET-CRANKCASE SPACER	002
QD663A1	GASKET-OIL PUMP	001
QD675	GASKET-ENGINE BASE	003
QD685	GASKET-OIL FILTER BASE	001
QD711	GASKET-IGN TIMER COVER	004
QD712	HEAD GASKET	002
QD757	HEAD GASKET (USE 757B)	001
QD757B	HEAD GASKET	004
QD799A		002
QD801	GASKET-INSPECTION PLATE	003
QD802	HEAD GASKET	008
QD825	HEAD GASKET	002
R114-9	USE R123	
R123	OIL FILLER & LEVEL ASSY	001
RC82	OIL CAP	001
RM457	BREATHER LINE ASSY	001
RM822	FUEL LINE 26-1/2" LONG	001
RM980	FUEL LINE	003
RM1122	TUBING ASSY (CK STOCK)	001
RV38S3	OIL FILTER PACK (CK STOCK)	002
RV40S4	OIL FILTER PACK (CK STOCK)	002
31S2437	POINT SET	003
SA68	COVER PLATE- VALVE INSPECTION	004
SA80	COVWER-OIL PUMP TROUGH	001
SD31	RETAINER SEAL	008
SD35	RETAINER-OIL SEAL	005
SD43	RETAINER SEAL	001
SE48B	SCREEN FLYWHEEL	001
SE53AS1	AIR SHROUD ASSY	002
SE74YD	SHROUD- AIR	001
SE124	FLYWHEEL SHROUD (VG4D)	001
SE137B	AIR SHROUD COVER	001
SE154	SHROUD- AIR FLYWHEEL	003
SE155	AIR SHROUD COVER	001
SE157	AIR SHROUD	001
SE158	SCREEN	001
SE161B4	SCREEN- ROTATING	002

Pat #	Description	Quantity in Stock
SE6D	AIR SHROUD	002
SW213	CHECK ITEM	004
93T57-4	WASHER	020
93C131-4X2	CHOKE SHAFT RETAINER	002
TB118	FLANGE MOUNTING-DISTRIBUTOR	001
TC301-3	PIN- GOV. SPRING	001
TC321	SPINDLE-GOV. WEIGHT	002
TC322S1	USE TC322DS1	
TC322DS1	FLYWEIGHT GOV. ASSY	001
TC323	SLEEVE	003
TC325	GOV. SHAFT SUPPORT BRACKET	001
TC328D	THRUST PIN	006
TC375	LEVER-GOVERNOR	003
TC379	FULCRUM PIN	001
TC381-1	PIN SUPPORT	002
TC432	LEVER - GOV. SHAFT	001
TT52	ASSEMBLY-VARIABLE SPEED(INSPECT	001
TT53	ASSEMBLY-VARIABLE SPEED(INSPECT	001
28TC4327E		001
63UCL5228A	PRESSURE PLATE ASSY.	001
U212	STARTING CRANK (USED)	003
U222A	STARTING CRANK	003
U226A	STARTING CRANK	001
U268	STARTER ROPE	002
UC63B		001
UC88ES1		002
63UCL7-1191-3	CLUTCH FACE	001
VB64A	YOKE SHIFTER	002
VB112	LEVER- SPEED CONTROL	001
VB234AS1	LEVER-GOV. ASSY	001
VB244	LEVER-GOV.	001
VC22C	X-BRACKET SPEED CONTROL	001
VC43A	DISC ASSY.	002
VE304	CONTROL ROD	001
VE363A	SPEED CONTROL ASSY.	025
VE440	CONTROL ROD	001
VE527W	THROTTLE CONTROL	004
VE555A	CONTROL ROD (VE877S1)	001
VE584A	SPEED CONTROL ASSY	001
VE683	CONTROL ROD (VE878S1)	002
VE783A	USE VE783B	
VE783B	GOV. CONTROL ROD	001

Pat #	Description	Quantity in Stock
VE877S1	CONTROL ROD	002
WA48A	TAKE OFF SHAFT WW25-14 CLUTCH	001
WC239		002
WD101	MUFFLER	002
WD64S1	MUFFLER	001
WD98S5	MUFFLER	001
WD370-1		001
WE193A	SUPPORT-ENGINE TAKE OFF END	003
WE243	SPACER-GEAR COVER (WE243-2S1)	001
WE262	DOOR UNIT HOUSE	002
WE306A	FUEL TANK	001
WE415S1	FUEL TANK	002
WW61E	POWER TAKE OFF ASSY	001
31X2427	CHECK ITEM	001
XD7	SCREW 1/4 X 20X1	005
XD13	SCREW 5-16-18X1/2	004
Y62	MAGNETO NO GEAR FOR AEN XH1995	001
Y72	MAGNETOR FOR AEH (FM X1B7E)	001
Y80S1	MAGNETO FOR TE-TF (NO COVER	001
Y95	MAGNETOR FOR VG4D (WICO)	001
Y109S1	MAGNETOR - NO GEAR	001
Y109CS1	MAGNETOR W/GEAR (FMXD1B7S)	001
Y117	MAGNETOR	002
YB16C	GENERATOR (USE YB16E)	
YB16E	GENERATOR	001
YC66S2		001
YC66S3		001
YC66S5		001
YD6S1	SPARK PLUG	007
YD20	PROTECTOR TERMINAL	001
YL285F	WIRE SET (BROKEN SET)	001
YQ5	POINT & CONDENSOR SET	002
YQ6	POINT & CONDENSOR SET	001
YQ7	POINT & CONDENSOR SET	001
YQ12	POINT & CONDENSORE SET	002
YQ21	DIST SERVICE KIT	006
YQ22	DIST SERVICE KIT (VE4 & VF4)	001
YQ25	DIST KIT	001
RD112-2	SCREEN - OIL PUMP	002
R114-9		001
R123	OIL FILLER & LEVEL ASSY	001
RK182		001

Pat #	Description	Quantity in Stock
RK181		002
SA68	COVER PLATE- VLAVE INSPECTION	001
31AZ2430	COVER	001
TC432	LEVER - GOV. SHAFT	001
DB218S5	PISTON .005 OVERSIZE	001
DA49A21S30	CONNECTING ROD .030 UNDERSIZE	001
DB210-2	PISTON STD.	001
DB183D-1S10	PISTON .010 OVERSIZE	002
PM74	SPRING TENSION	002
PL17	KEY-WOODRUFF 13	007
PH612		006
PH557A	SEAL-OIL	002
PH426	GROMMET 1-13/16	001
PH364	SEAL-OIL	001
PH318-A		003
PH282	WASHER-SPRING	002
PH280	SEAL-OIL	002
93C29283		001
93C29875	THROTTLE&SHAFT	001
93C29926	THROTTLE&SHAFT	002
93C8597	FLOAT	001
63CL1418	CLUTCH FACING 1/8	013
63CL1419	CLUTCH FACING 5/32	014
X4201D	COLLAR ASSY.	002
78-4955	DRIVER PLATE	002
78-4958	DRIVER PLATE (FOR WC-220-2 AGND)	003
63CL4966	YOKE FOR TE-TF (USE63UCL14-4966)	001
63CL4971	ROLLER PIN (USE 63LM408)	003
63CL4776	LINK	006
63CL5145	RELEASE SLEEVE	001
63UCL5228A	PRESSURE PLATE	001
63CL5522	LOCK-ADJ.	001
63CL5543	LEVER	004
0651-49-960	OIL FILTER DIESEL WD-2-860	004
EY0440250070	SEAL OIL (ROBIN)	004
EY2073350113	EXHAUST VALVE (ROBIN)	001
EY25W6002	AIR CLEANER CHECK STOCK	
EY25W	RECOIL STARTER (MISC.PIECES)	